



## Hand Demag PDM 105

Hand held Demagnetiser



### OPERATION

1. Connect to a 110Volt AC supply. 4Amp Rating.
2. Place onto workpiece
3. Press and hold Red button whilst wiping over surface.
4. Remove from workpiece before releasing the switch
5. The unit is intermittently rated and the time the demagnetiser is operated off the workpiece should be kept to a minimum.
6. If the thermal cut out operates, allow to cool. Thermal cut out will automatically re-set.

**Johnson and Allen Ltd, Neocol works, Smithfield, Sheffield S3 7AR**  
**Tel +44 (0)114 2738066 Fax + 44(0) 114 2729842**  
**e-mail [info@johnsonandallen.co.uk](mailto:info@johnsonandallen.co.uk)**